

PANEL OPERATION

10 SUPERVISORY CONDITION



SYSTEM TROUBLE

11 IDC ZONE LED

RED
AMBER
AMBER
AMBER


12 OPTION MODULES

OPTION MODULES




13 LED LEGEND

LED OFF
LED ON STEADY
SLOW FLASH
RAPID FLASH



15 ALARM

ALARM



6 POWER

POWER

4 ACTIVE ZONE DISCONNECT

5 ZONE DISCONNECT

ZONE DISABLED

7 DRILL

8 LAMP TEST

DRILL

LAMP TEST

1 ALARM SILENCE

ALARM SILENCE

2 SYSTEM RESET

SYSTEM RESET

3 TROUBLE BUZZER SILENCE

TROUBLE BUZZER SILENCE

4 ZONE DISCONNECT

ZONE DISCONNECT

(A1PRG4 CDR)